

FIAT BSI WIRING DIAGRAMS 2

#FIAT BSI DELPHI 70F3556

#FIAT BSI DELPHI 70F3379+93C86

#FIAT BSI DELPHI 70F3237+93C86

#FIAT BSI DELPHI 70F3633

#FIAT BSI MAGNETI MARELLI 3K91D

#FIAT BSI MAGNETI MARELLI 1K79X

#FIAT BSI MAGNETI MARELLI 70F3237+95160

#FIAT BSI MAGNETI MARELLI 70F3378+95160




#FIAT BSI MAGNETI MARELLI 70F3633+95320

#FIAT BSI SIEMENS/CONTINENTAL 9S12DG128

#FIAT BSI MAGNETI MARELLI MB91465P+95640


#FIAT BSI CONTINENTAL MPC5606

FIAT BSI DELPHI 70F3633





| | | | |
|--------|-----|------|------|
| +12V | GND | CANH | CANL |
| A, C11 | C10 | B59 | B60 |

Connecting directly to ioterminal




FIAT BSI DELPHI 70F3379+93C86








| | | | |
|---------------|------------|-------------|-------------|
| +12V | GND | CANH | CANL |
| A, C11 | C10 | B59 | B60 |

Connecting directly to ioterminal




FIAT BSI DELPHI 70F3237+93C86




| | | | |
|-------|-----|------|------|
| +12V | GND | CANH | CANL |
| A,D32 | C10 | D21 | D22 |

Connecting directly to ioterminal




FIAT BSI MAGNETI MARELLI 70F3237+95160
FIAT BSI MAGNETI MARELLI 70F3378+95160
FIAT BSI MAGNETI MARELLI 3K91D
FIAT BSI MAGNETI MARELLI 1K79X




A9 - IGNITION

Connecting directly to ioterminal




FIAT BSI SIEMENS/CONTINENTAL 9S12DG128






A1 - IGNITION

Connecting directly to ioterminal




WWW.IOTERMINAL.COM

FIAT BSI MAGNETI MARELLI 70F3633+95320




A2 - IGNITION






| | | | |
|-------|-----|------|------|
| +12V | GND | CANH | CANL |
| A2, C | A11 | B24 | B9 |


Connecting directly to ioterminal



FIAT BSI MAGNETI MARELLI MB91465P+95640 BACK




A2 - IGNITION








| | | | |
|-------|-----|------|------|
| +12V | GND | CANH | CANL |
| A2, C | A11 | B24 | B9 |

Connecting directly to ioterminal




FIAT BSI DELPHI 70F3556






| | | | |
|---------------|------------|-------------|-------------|
| +12V | GND | CANH | CANL |
| C, B12 | A11 | B52 | B53 |

Connecting directly to ioterminal



FIAT BSI CONTINENTAL MPC5606



| | | | |
|----------------------------|-------------|-------------|-------------|
| +12V | GND | CANH | CANL |
| E-17 E-18 | A-19 | A-20 | A-10 |

Connecting directly to ioterminal

